

HTX & SXHT Series Hydronic Expansion Tanks

QUICK SIZING GUIDE

| Boiler Output 1000's BTUH | Copper Baseboard & Radiant | Type of Radiation | | |
|---------------------------------|-------------------------------------|---------------------------------|-----------|-----------|
| | | Convectors & Unit Heaters | Cast Iron | |
| | | | Radiators | Baseboard |
| 25 | HTX 15 | HTX 15 | HTX 15 | HTX 15 |
| 50 | HTX 15 | HTX 30 | HTX 30 | HTX 30 |
| 75 | HTX 30 | HTX 30 | HTX 60 | HTX 60 |
| 100 | HTX 30 | HTX 30 | HTX 60 | HTX 60 |
| 125 | HTX 30 | HTX 60 | HTX 60 | HTX 60 |
| 150 | HTX 30 | HTX 60 | HTX 90 | HTX 90 |
| 175 | HTX 60 | HTX 60 | HTX 90 | HTX 90 |
| 200 | HTX 60 | HTX 60 | HTX 90 | HTX 90 |
| 250 | SXHT 30 | SXHT 30 | SXHT 40 | SXHT 30 |
| 300 | SXHT 30 | SXHT 40 | SXHT 40 | SXHT 30 |
| 350 | SXHT 30 | SXHT 40 | SXHT 60 | SXHT 40 |
| 400 | SXHT 30 | SXHT 60 | SXHT 90 | SXHT 40 |
| 500 | SXHT 40 | SXHT 60 | SXHT 90 | SXHT 40 |
| 600 | SXHT 40 | SXHT 90 | SXHT 90 | SXHT 60 |
| 700 | SXHT 60 | SXHT 90 | SXHT 90 | SXHT 60 |
| 800 | SXHT 60 | SXHT 110 | SXHT 110 | SXHT 90 |
| 900 | SXHT 60 | SXHT 110 | SXHT 110 | SXHT 90 |
| 1000 | SXHT 90 | SXHT 110 | SXHT 110 | SXHT 90 |

Sizing recommendations based on average size systems.

Fill pressure 12 PSI. Relief valve 30 PSI.

Average system water temperature 200°F.

300 Pond Street, Randolph, Massachusetts 02368

Call 1.781.986.2424 • Fax 1.781.986.2029

www.flexconind.com